

Clarke®

WORX



PLASMA CUTTERS

Model Nos.
King 35 • King 50 • King 70

OPERATING & MAINTENANCE INSTRUCTIONS





For wiring diagrams and parts lists, please refer to the accompanying booklet.

SPECIFICATIONS

	<u>King35</u>	<u>King50</u>	<u>King70</u>
Supply Voltage	230V	230V	230/400V
No. of phases	1PH	1PH	3PH
Frequency	50/60HZ	50/60 HZ	50/60 HZ
Max. Input Current (230V)	18A	31A	46A
Max. Input Current (400V)	-	-	26A
Fuse Rating	T20A (230V)	T30A (230V)	T35A(230) T25A(400)
Cutting Depth - (Steel Class C)	4MM	10MM	15MM
No. Current Settings	1	2	2
Working Air Pressure	5 to 5.5 BAR	5 to 5.5 BAR	5 to 5.5 BAR
Rated Air Delivery	100 L/MIN	105 L/MIN	210 L/MIN
Protection	IP21	IP21	IP21
Insulation Clas	H	H	H
Weight	30KG	50KG	83KG
Dimensions	250x500x380	456x610x695	456x610x695



Thank you for purchasing this CLARKE Plasma Cutter .
Before attempting to operate this machine, please read this leaflet thoroughly and follow the instructions carefully, in doing so you will ensure the safety of yourself and that of others around you, and you can look forward to the Plasma Cutter giving you long and satisfactory service.

GUARANTEE

This CLARKE product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission.

This guarantee does not effect your statutory rights.

CONTENTS

Page

Specifications	1
EMC Regulations	3
Safety Precautions - General	5
Additional Safety Precautions for Plasma Cutters	7
What is Plasma Cutting	8
Features	8
Air Supply	9
Front Panel Description	9
Electrical Connections	11
Installation & Operation	12
Duty Cycle	14
Maintenance	15
Troubleshooting	16

ELECTROMAGNETIC INTERFERENCE (EMC)

Whilst this unit complies with EMC regulations, the user is responsible for installing and using the welding equipment according to the manufacturers instructions. If electromagnetic disturbances are detected then it shall be the responsibility of the user of the welding equipment to resolve the situation. In some cases this remedial action may be as simple as earthing the welding circuit, see 'Note'. In other cases it could involve constructing an electromagnetic screen enclosing the power source and the work complete with associated input filters. In all cases electromagnetic disturbances must be reduced to the point where they are no longer troublesome.

Note - The welding circuit may or may not be earthed for safety reasons. Changing the earthing arrangements should only be authorised by a person who is competent to assess whether the changes will increase the risk of injury, e.g. by allowing parallel welding current return paths which may damage the earth circuits of other equipment.

1. Assessment of area

Before installing welding equipment the user shall make an assessment of potential electromagnetic problems in the surrounding area. Avoid using your inverter in the vicinity of:

- a) other supply cables, control cables, signalling and telephone cables; above, below and adjacent to the welding equipment;
- b) radio and television transmitters and receivers;
- c) computer and other control equipment;
- d) safety critical equipment, e.g. guarding of industrial equipment;
- e) pacemakers and hearing aids etc;
- f) equipment used for calibration or measurement;
- g) other equipment in the environment. The user shall ensure that other equipment being used in the environment is compatible. This may require additional protection measures;

It may be possible to avoid the above by changing the time of day that welding or other activities are to be carried out.

The size of the surrounding area to be considered will depend on the structure of the building and other activities that are taking place. The surrounding area may extend beyond the boundaries of the premises.

2. Methods of reducing emissions

2.1 Mains supply

Welding equipment should be connected to the mains supply according to the manufacturers recommendations. If interference occurs, it may be necessary to

take additional precautions such as filtering of the mains supply. Consideration should be given to shielding the supply cable of permanently installed welding equipment, in metallic conduit or equivalent. Shielding should be electrically continuous throughout its length. The shielding should be connected to the welding power source so that good electrical contact is maintained between the conduit and the welding power source enclosure.

2.2 Maintenance of the welding equipment

The welding equipment should be routinely maintained according to the manufacturers recommendations. All access and service doors and covers should be closed and properly fastened when the welding equipment is in operation. The welding equipment should not be modified in any way except for those changes and adjustments covered in the manufacturers

instructions. In particular, the spark gaps of arc striking and stabilizing devices should be adjusted and maintained according to the manufacturers recommendations.

2.3 Welding cables

The welding cables should be kept as short as possible and should be positioned close together, running at or close to the floor level.

2.4 Equipotential bonding

Bonding of all metallic components in the welding installation and adjacent to it should be considered. However, metallic components bonded to the work piece will increase the risk that the operator could receive a shock by touching these metallic components and the electrodes at the same time. The operator should be insulated from all such bonded metallic components.

2.5 Earthing of the workpiece

Where the workpiece is not bonded to earth for electrical safety, nor connected to earth because of its size and position, e.g. ships hull or building steelwork, a connection bonding the workpiece to earth may reduce emissions in some, but not all instances.

Care should be taken to prevent the earthing of the workpiece increasing the risk of injury to users, or damage to other electrical equipment.

Where necessary, the connection of the workpiece to earth should be made by a direct connection to the workpiece, but in some countries where direct connection is not permitted, the bonding should be achieved by suitable capacitance, selected according to national regulations.

2.6 Screening and shielding

Selective screening and shielding of other cables and equipment in the surrounding area may alleviate problems of interference. Screening of the entire welding installation may be considered for special applications.

SAFETY PRECAUTIONS

WARNING:

As with all machinery, there are certain hazards involved with their operation and use. Exercising respect and caution will considerably lessen the risk of personal injury. However, if normal safety precautions are overlooked, or ignored, personal injury to the operator may result.

FAILURE TO FOLLOW THESE RULES MAY RESULT IN SERIOUS PERSONAL INJURY

GENERAL PRECAUTIONS

A) Burn prevention

Wear protective clothing - gauntlet gloves designed for use in welding, hat, and protective shoes. Button shirt collar and pocket flaps, and wear cuffless trousers to avoid entry of sparks and slag. Wear helmet with safety goggles or glasses with side shields underneath, appropriate filter lenses or plates (protected by clear cover glass). This is a MUST for welding or cutting, (and chipping) to protect the eyes from radiant energy and flying metal. Replace cover glass when broken, pitted, or spattered. Avoid oily greasy clothing. A spark may ignite them. Hot metal such as electrode stubs and workpieces should never be handled without gloves. First aid facilities and a qualified first aid person should be available for each shift unless medical facilities are close by for immediate treatment of flash burns of the eyes and skin burns. Ear plugs should be worn when working overhead or in a confined space. A hard hat should be worn when others work overhead. Flammable hair preparations should not be used by persons intending to weld or cut.

B) Toxic fume prevention

Severe discomfort, illness or death can result from fumes, vapours, heat, or oxygen enrichment or depletion that welding (or cutting) may produce. Prevent them with adequate ventilation. NEVER ventilate with oxygen. Lead-, cadmium-, zinc-, mercury- and beryllium-, bearing materials, when welded (or cut) may produce harmful concentrations of toxic fumes. Adequate local exhaust ventilation must be used, or each person in the area as well as the operator must wear an air-supplied respirator. For beryllium, both must be used. Metals coated with or containing materials that emit toxic fumes should not be heated unless coating is removed from the work surface, the area is well ventilated, or the operator wears an air-supplied respirator. Work in a confined space only while it is being ventilated and, if necessary, while wearing an air-supplied respirator. Vapours from chlorinated solvents can be decomposed by the heat of the arc (or flame) to form PHOSGENE, a highly toxic gas, and other lung and eye irritating products. The ultraviolet (radiant) energy of the arc can also decompose trichloroethylene and perchloroethylene vapours to form phosgene. DO NOT WELD or cut where solvent vapours can be drawn into the welding or cutting atmosphere or where the radiant energy can penetrate to atmospheres containing even minute amounts of trichloroethylene or perchloroethylene.

C) Fire and explosion prevention

Causes of fire and explosion are:

- 1) combustibles reached by the arc, flame, flying sparks, hot slag or heated material;
- 2) misuse of compressed gases and cylinders;
- 3) short circuits.

BE AWARE THAT flying sparks or falling slag can pass through cracks, along pipes, through windows or doors, and through wall or floor openings, out of sight of the goggled operator. Sparks and slag can fly 10m.

To prevent fires and explosion: keep equipment clean and operable, free of oil, grease, and (in electrical parts) of metallic particles that can cause short circuits. If combustibles are in area, do NOT weld or cut. Move the work if practicable, to an area free of combustibles.

Avoid paint spray rooms, dip tanks, storage areas, ventilators. If the work cannot be moved, move combustibles at least 10m. away out of reach of sparks and heat; or protect against ignition with suitable and snug fitting, fire-resistant covers or shields.

Walls touching combustibles on opposite sides should not be welded on (or cut).

Walls, ceilings, and floor near work should be protected by heat resistant covers or shields. Fire watcher must be standing by with suitable fire extinguishing equipment during and for some time after welding or cutting if:

- a) appreciable combustibles (including building construction) are within 10m.
- b) appreciable combustibles are further than 10m but can be ignited by sparks.
- c) openings (concealed or visible) in floors or walls within 10m can expose combustibles to sparks.
- d) combustibles adjacent to walls, ceilings, roofs or metal partitions can be ignited by radiant or conducted heat.

After work is done, check that area is free of sparks, glowing embers, and flames. An empty container that held combustibles, or that can produce flammable or toxic vapours when heated, must never be welded on or cut, unless container has first been cleaned. This includes

.....a thorough steam or caustic cleaning (or a solvent or water washing, depending on the combustible's solubility) followed by purging and inerting with nitrogen or carbon dioxide, and using protective equipment.

Water filling just below working level may substitute for inerting.

A container with unknown contents should be cleaned (see paragraph above), do NOT depend on sense of smell or sight to determine if it is safe to weld or cut.

Hollow castings or containers must be vented before welding or cutting - they can explode.

In explosive atmospheres, never weld or cut where the air may contain flammable dust, gas, or liquid vapours.

ADDITIONAL SAFETY PRECAUTIONS FOR PLASMA CUTTERS

The safety precautions given previously must be strictly adhered to. The following precautions are additional to, and focus specifically on Plasma Cutters.

- ✓ **ALWAYS** have a fire extinguisher handy when operating the cutter.
- ✓ **ALWAYS** wear protective clothing - overalls, gloves and sturdy footwear, To avoid the risk of burns,
- ✓ **ALWAYS** ensure that the cutting cable, air compressor hose and electrical input lead are kept well away from the possible 'spatter' of hot metal created when cutting.
- ✓ **ALWAYS** operate the cutter in a well ventilated area or an area equipped with a fume extractor. Check the possibility that the material to be cut will give off toxic gas or fumes. If there is any doubt, a respirator should worn.

- ✗ **NEVER** operate near water or any other liquid.
- ✗ **NEVER** operate near anything flammable. Whilst plasma cutters do not produce an open flame, they do produce very hot metal during the cutting process, hot enough to set alight flammable materials, should contact be made.
- ✗ **NEVER** observe the electric plasma arc with the naked eye. Always wear eye protection such as welding goggles used for oxy-acetylene welding.
- ✗ Should the cutting cable be burned, replace it **NEVER** attempt to repair it yourself.
- ✗ **NEVER** operate the machine with the covers removed.
- ✗ **NEVER** dismantle the tip from the torch unless the machine has been disconnected from the electrical supply.
- ✗ **NEVER** push the torch nozzle down with your hands unless the machine has been disconnected from the electrical supply.
- ✗ **NEVER** cut fuel or lubricant containers, even if they are empty.
- ✗ **NEVER** cut containers or casings which contain flammable material.
- ✗ **NEVER** cut in environments which are polluted by flammable gas or combustible vapours, such as petrol etc.
- ✗ **NEVER** point the torch jet at people or animals.

- ⚠ Should you feel sick or develop sore eyes whilst using the plasma cutter, **STOP WORK IMMEDIATELY** and move to fresh air. Do not resume cutting until you have provided good ventilation for the cutting area.
- ⚠ When halogenated solvents or degreasing agents are present, the material to be cut should be cleaned properly to prevent the formation of toxic gases. Some chlorinated solvents may decompose in the presence of the radiation given out by the arc and may generate phosphene gas.

WHAT IS PLASMA CUTTING

Plasma Cutting is a fast, clean and distortion free, means of cutting through all types of metal from mild and stainless steels to aluminium brass and copper.

The process relies upon the chemical reaction of a gas or mixture of gases, such as air, when subjected to very high temperatures. The gas ionises, i.e. negative electrons are separated from the atom, leaving the atom positively charged. In this ionised state, the gas is electrically conductive and is called 'plasma'.

A standing electric arc is created to achieve the very high temperature required to create the plasma. By forcing the plasma through a small nozzle the arc is constricted and its temperature is increased to over 20,000°C and concentrated into a very small area.

When the plasma is directed at a conductive material (which is connected to the earth return lead of the cutter) the arc is transferred through the plasma to the material. The high energy of the arc melts the material which is displaced by the gas flow.

The standing arc has to be created by producing an ionised path in the gas. This is achieved by applying a very high voltage, at high frequency, between the electrode and the tip/work, causing a high frequency spark. The main arc will ignite as soon as the gas between the tip and the nozzle is ionised.

The power generator is essentially made up of a transformer, a rectifying unit and an electronic board.

The latter controls the unit safeguards and governs the work cycles of the various components which make up the unit, such as the solenoid valve, the HF circuit (for models fitted with this), the power contactor, etc.

FEATURES

The plasma cutting units are supplied with the following safety devices:


1. Thermal protection devices are installed at the points most subject to high temperatures such as the power transformers and the rectifying units.
An amber light on the front panel lights up when the thermal protection device intervenes. See fig.3
2. A pneumatic protection device prevents damage to the torch due to switching on with either no air supply or low air pressure.
An amber light on the front panel lights up when the pneumatic protection device intervenes. See fig. 3
3. An Electric shock protection device prevents the operator from coming into contact with the live parts of the torch (such as the electrode, etc.) This consists of a safety device, built into the body of the torch, which breaks the main power circuit when the end part of the torch is removed to replace the electrode or the tip.
When the electrical protection device intervenes, the unit is prevented from operating.

MAIN COMPONENTS

The power generator is essentially made up of a transformer, a rectifying unit and an electronic board.

The latter controls the unit safeguards and governs the work cycles of the various components which make up the unit, such as the solenoid valve, the power contactor, etc.

Fig. 1




AIR SUPPLY

A compressed air supply is required, capable of delivering **clean dry air**, at a minimum pressure of 6 Bar, and at a rate of, from 100 to 210 litres per minute, depending upon the model. (See Specifications on page 2).

GENERAL LAYOUT


KING 35 - FRONT PANEL

Fig. 2



KING 50 & 70 - FRONT PANEL

Fig. 3



ELECTRICAL CONNECTIONS

A. KING 35 & KING 50

Connect the mains lead, through a suitably fused isolator switch, to a 230 Volt (50Hz) electrical supply, having a fuse rating in accordance with that given in the specification chart on page 2. A standard 13 Amp plug **MUST NOT** be used with this machine.

WARNING! THIS APPLIANCE MUST BE EARTHED

IMPORTANT: The wires in the mains lead are coloured in accordance with the following code:

Green & Yellow	-	Earth
Blue	-	Neutral
Brown	-	Live

As the colours of the flexible lead of this appliance may not correspond with the coloured markings identifying terminals in your electrical supply, proceed as follows:

- Connect GREEN & YELLOW coloured cord to terminal marked with a letter "E" or Earth symbol "⏏" or coloured GREEN or GREEN & YELLOW.
- Connect BROWN cord to terminal marked with a letter "L" or coloured RED.
- Connect BLUE cord to terminal marked with a letter "N" or coloured BLACK.

B. KING 70

This model is designed for use with either **230V three phase or 400V three-phase** supply, and should be connected through a suitably fused isolator switch.


The GREEN or GREEN & YELLOW wire should be connected to the EARTH terminal or terminal marked with "⏏" symbol. The other two wires are for connection to the phase wires.

The machines are delivered for connection to a 400V supply, but to be certain, check the label on the end of the power supply cable, or remove the cover and visually inspect the Voltage changeover block. (see fig. 4).

If the supply voltage is changed, a corresponding change must be made to the terminal connectors on the 'Voltage Changeover' block, located behind the right hand side panel, as follows:

1. Ensure the machine is switched OFF, and completely disconnected from the electrical supply, or if hard wired, the fuse should be removed from the circuit.
2. Remove the right hand side panel by unscrewing the 6 securing screws.
3. Change the connections of the 'Voltage Changeover' block, as shown on the label inside the unit, which is duplicated above at fig 4.

Fig. 4



CAUTION: Never operate the machine with the panels removed.

INSTALLATION AND OPERATION

On receipt, check the unit for any damage which may have occurred during transportation. You should immediately report such damage to the Clarke dealer from whom the unit was purchased.

A. KING 35

This model is provided with a regulator and air filter assembly, which is mounted on the rear panel as shown in fig 5.

Attach the air hose by simply pushing the hose into the connector.

To remove the hose, hold the clamping ring IN, whilst pulling on the hose, as shown in fig.6




Fig. 6

Attach the handle by snapping the lugs into the slotted holes in the top of the machine, then screwing in the two securing screws.




Fig. 5

B. KING 50 & KING 70.

- (i) Attach the handle to the unit by inserting the ends into the holes in the upper corners of the front panel, and securing with the four self tapping screws provided.
- (ii) Gently, and with assistance, tip the unit over so that it rests on the handle, and edge of the front panel, and insert the axle into its' housing. Attach the wheels, and secure in position with circlips provided.
- (iii) Push the two castors firmly home into the holes provided, and gently lift the machine to an upright position.

C. ALL MODELS

1. Connect the power supply cable to a source located as near as possible to the work area, so that the unit can be switched off quickly in case of emergency. Refer to 'Electrical Connections' on page 12. Fuse ratings are given in the Specification chart on page 2.

Make sure that the mains supply switch and any fuses have a value which is the same or 20% above the maximum current absorbed by the unit. (See Specification chart page 2)

- Pull out the air pressure regulator knob, (located on the front panel (King 50 & 70), or at the back of the unit (King 35), and turn it fully clockwise before connecting the air hose to the compressed air supply. This ensures the regulator is set to its lowest pressure. Make sure that the supply pressure is at least 6 bar (from 6 to 8 is ideal).

Turn the air supply to the unit 'on', and set a pressure of 5 to 5.5 bar by screwing the regulator knob anticlockwise, whilst observing the pressure on the gauge. When the pressure is set, lock the knob in position, by pushing it 'in'.

- Fasten the earth clamp to the workpiece. If a metal bench is being used, make sure it has also been connected to earth by means of a cable with an adequate cross-section. If the surface of the piece to be cut is painted, rusty or covered with insulating material, clean the surface so that satisfactory contact between the workpiece and the earth clamp can be obtained.
- Make sure that the torch has been assembled with the correct components and that the hole in the tip of the torch complies with the values given in the table below, according to the cutting current. Simply unscrew the nozzle, and replace with one of the required size.
- Switch the unit ON using the main switch (see Figs 2 & 3), Select the appropriate current in the case of King50 and King70. A hissing of air will be apparent for a short period, as the air system is charged and the air filter drain valves close

PLASMA UNIT	TORCH	TIP HOLE (mm)	CUT CURRENT (Amps)
King 25	Binzel PSB31	1	25
King 50	S54	1	35/50
King 70	A90	1,1•1,4•1,7	40/70

- Check to ensure the amber lights for air supply, and torch safety, (i.e. Thermal Overload), situated on the front panel, are off. The green light should be 'on', indicating that the unit is supplied with power.
- Press the torch button and check whether the pressure indicated by the pressure gauge corresponds to the pressure required. At the same time, the Pilot Arc will light. Because these models are fitted with a Pilot Arc, cutting can commence even on metal which is painted or coated. However, do be aware that fumes may be given off by burning paint or coated surfaces.
- The pilot arc will go out after 2-3 seconds. If in the meantime cutting has not started, the torch button should be pressed again so that pilot arc will relight.

CAUTION:
Avoid unnecessary lighting of the pilot arc, to prevent excessive consumption of the electrode and nozzle.

9. To start cutting, bring the torch with the pilot arc near to the workpiece and the cutting arc between the torch and the workpiece will immediately light. If piercing or cutting is to be carried out from the centre of the piece, start cutting with the torch inclined and then straighten it slowly so that molten metal does not spray onto the nozzle of the torch. If this operation is to be carried out on thicknesses greater than 3-4mm, first drill a hole from which the cutting can start.
10. During cutting, rest the nozzle perpendicularly on the surface to be cut without exerting any force. The wire spacer, mounted on the end of the torch, (except King 35), should be used in all cutting operations, to maintain the correct gap between the torch and the workpiece. To move the torch, pull towards you rather than pushing away from you.

CAUTION:

During cutting, the speed of torch movement should correspond to the thickness of the workpiece.

Moving too quickly causes a return of incandescent scale towards the torch, which shortens the life span of the parts most subject to wear and tear. The build up of scale on the nozzle should be removed as soon as possible.

11. To stop cutting remove the torch from the workpiece. To extinguish the pilot arc release the trigger on the torch.

Note:

When the trigger is released and the arc is extinguished compressed air will continue to flow for a period of time, in order to cool the torch. DO NOT switch off the machine until the air has stopped flowing or damage may occur to the torch.

IMPORTANT WARNING:

WHEN YOU LIFT THE TORCH AWAY FROM THE WORKPIECE THE CUTTING ARC WILL BE LOST BUT THE PILOT ARC WILL REMAIN IGNITED IN THE NOZZLE UNTIL THE TORCH TRIGGER IS RELEASED.

NEVER TOUCH THE NOZZLE WHILST THE PILOT ARC IS IGNITED AS THIS MAY RESULT IN SERIOUS INJURY.

DUTY CYCLE

The duty cycle of a plasma cutting unit is determined by the percentage of use in a repetitive cycle of 10 minutes with a given cutting current " I_2 ".

The duty cycle is indicated by the letter "X" on the table of technical specifications which is screen-printed on the rear panel of the unit.

For example: X=30%	$I_2=50A$
X=100%	$I_2=30A$

In the first case the operator can cut for 3 minutes (30%), with a 50A current; in the second case the operator can cut for 10 minutes (100%) with a 30A current.

Do not overwork the machine, operating above the established duty cycle may cause serious damage.

MAINTENANCE

A. THE BASE UNIT

If any fault develops, it must be repaired by a qualified technician only. Contact your CLARKE dealer for advice. Maintenance of the unit is limited to the following.

1. If the machine is in constant use, inspect every 3-4 months, and use **dry** compressed air to remove any dust deposit. Ensure all precautions are taken with regard to the use of compressors to clean the electronic components.
2. Check the air filter regularly. Condensate is drained off immediately the compressed air supply is removed from the machine. Whenever the machine is not used for 1 week or more, the compressed air supply should be disconnected completely. On models King 50 & 70, the air filter assembly is to be found beneath the cover, on the left hand side of the machine.

To drain the condensate, turn the knurled nut (see fig. 7), anticlockwise so that the drain is fully open. Remember to screw the nut in again once the condensate has drained.



Fig. 7

B. THE TORCH ASSEMBLY

WARNING
*NEVER ATTEMPT TO CARRY OUT ANY MAINTENANCE ON THE TORCH,
UNLESS THE MAINS SUPPLY IS DISCONNECTED*

No special tools are required to replace torch parts. Simply unscrew the nozzle assembly, and all components are easily replaced.

1. The torch must be kept free of slag at all times, to ensure the free passage of air.
2. Check the condition of the electrode. One which is worn, i.e. has a crater 1.5 to 2mm deep at its centre, should be renewed. Unscrew the electrode only when the cooling air flow has finished, to avoid damage to the torch body.
3. Check to ensure the hole in the nozzle is not too wide or deformed, as this may cause problems for the cutting arc. A nozzle with a damaged or enlarged hole should be renewed.
4. Check to ensure the holes in the protective ring are clear. Blocked holes or a damaged ring may damage the torch due to overheating.
5. Check the condition of the torch sheath, ensuring that no parts are worn or cut, or there are no signs of electrical discharge. A damaged sheath should be renewed.

TROUBLE SHOOTING

1. PLASMA CUTTER DOESN'T WORK

Check the indicator lamps on the front panel. If Green light is OFF, check power cable and electrical input - fuse etc.

If the amber Air Supply light is ON - Check compressed air supply, flow and pressure.

If Thermal Overload lamp is ON - wait for a while and let the plasma cutter cool down. It will automatically reset when it is ready to start cutting again.

2. PLASMA CUTTER DOESN'T WORK

- both amber lights OFF, power light ON.

Check plasma electrode, it may have to be replaced. On the King 35, check to ensure the safety clip is firmly in place

3. RAGGED CUT AND LACK OF POWER

Check the hole in the nozzle. If it is burned too big or egg Shaped replace it. Check the air supply. Make sure that the moisture is drained out of the filter regulator.

4. NOT CUTTING AS IT SHOULD

You might be trying to cut metal that is too thick, or you may be trying to cut too fast. Move the cutting torch slower.

5. ARC GOES OUT WHEN YOU ARE CUTTING

You are probably moving the torch too slow. Move the Cutting torch faster.

6. RAGGED EDGES ON THE MATERIAL YOU ARE CUTTING

Air pressure could be set too high on the filter regulator. It should be set at 5 to 5.5 Bar. You could be holding the torch too high above the metal you are cutting. Always use the wire spacer mounted on the end of the torch to maintain the correct clearance between the tip, and the workpiece.