

Charlke®



SHHH AIR COMPRESSOR

Model No. SHHH 2/10

Part No: 2320757

OPERATING & MAINTENANCE INSTRUCTIONS



© 0805



SPECIFICATIONS

Max. Pressure	8 bar (120psi)
Air Intake	1.1cfm (25Lpm)
Air Displacement @ 5bar	0.65cfm (18.0Lpm)
Electric Motor	0.19kW (0.25HP)
Receiver Capacity	9 Litre
Fuse Rating	13amps
Duty Cycle	15 mins ON - 15 mins OFF
Part No.	2320757
Dimensions	34x34x50cm
Sound Power Level	40dBA
Compressor Oil	500mL, Synthetic Oil
Oil Part No.	3050795

PARTS & SERVICE

For Spare Parts and Service, please contact your nearest dealer,
or CLARKE International, on one of the following numbers.

PARTS & SERVICE TEL: 020 8988 7400

PARTS & SERVICE FAX: 020 8558 3622

or e-mail as follows:

PARTS: Parts@clarkeinternational.com

SERVICE: Service@clarkeinternational.com

Clarke

air



Thank you for purchasing this CLARKE Shhh Air silent running air compressor

Before attempting to operate the machine, please read this leaflet thoroughly and carefully follow the instructions given. In doing so you will ensure the safety of yourself and that of others around you, and you can also look forward to the compressor giving you long and satisfactory service.

GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt as proof of purchase. This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned without prior permission. This guarantee does not effect your statutory rights.

CONTENTS

Page

Specifications	2
Parts & Service	2
Safety Precautions	4
Electrical Connections	5
Parts Identification	6
Preparation for Use	6
Operation	6
Shutting Down	8
Maintenance	8
Fault Finding	10
Accessories	11
Declaration of Conformity	11

SAFETY PRECAUTIONS

WARNING

As with all machinery, there are certain hazards involved with their operation and use. Exercising respect and caution will considerably lessen the risk of personal injury. However, if normal safety precautions are overlooked, or ignored, personal injury to the operator, or damage to property may result.

It is in your own interest to read and pay attention to the following rules:

1. COMPRESSED AIR IS DANGEROUS, NEVER direct a jet of air at people or animals, and NEVER discharge compressed air against the skin.
2. ALWAYS place the compressor on a flat horizontal surface.
3. Electrical or mechanical repairs should only be carried out by a qualified engineer. If problems occur, contact your Clarke dealer.
4. Before carrying out any maintenance, ensure the pressure is expelled from the air receiver, and the machine is disconnected from the mains supply.
5. DO NOT leave pressure in the receiver overnight, or when transporting.
6. DO NOT adjust, or tamper with the safety valves. The maximum pressure is factory set, and clearly marked on the machine.
7. DO NOT operate in wet or damp conditions. Keep the machine dry at all times. Similarly, a clean atmosphere will ensure efficient operation. Do not use in dusty or otherwise dirty locations.
8. Some of the metal parts can become quite hot during operation. Take care not to touch these until the machine has cooled down.
9. Always adjust the pressure regulator to the recommended setting for the particular spray gun or tool being used.
10. When spraying flammable materials e.g. cellulose paint, ensure that there is adequate ventilation and keep clear of any possible source of ignition.
11. Protect yourself. Think carefully about any potential hazards which may be created by using the air compressor and use the appropriate protection. e.g. Goggles will protect your eyes from flying particles. Face masks will protect you against paint spray and/or fumes.
12. Before spraying any material always consult paint manufacturers instructions for safety and usage.
13. Do not exert any strain on electrical cables and ensure that air hoses are not angled or wrapped around machinery etc.
14. When disconnecting air hoses or other equipment from your compressor ensure that the air supply is turned off at the machine outlet and expel all pressurised air from within the machine and other equipment attached to it.
15. Make sure that children and animals are kept well away from the compressor and any equipment attached to it.
16. Always ensure that all individuals using the compressor have read and fully understand these Operating Instructions.
17. Ensure that any equipment or tool used in conjunction with your compressor, has a safety working pressure exceeding that of the machine.

ELECTRICAL CONNECTIONS

Connect the mains lead to a standard, 230 Volt (50Hz) electrical supply through an approved 13 amp BS 1363 plug, or a suitably fused isolator switch.



WARNING! THIS APPLIANCE MUST BE EARTHED

IMPORTANT: The wires in the mains lead are coloured in accordance with the following code:

Green & Yellow - Earth
Blue - Neutral
Brown - Live

As the colours of the flexible lead of this appliance may not correspond with the coloured markings identifying terminals in your plug proceed as follows:

- Connect GREEN & YELLOW cord to terminal marked with a letter "E" or Earth symbol "⏏" or coloured GREEN or GREEN & YELLOW.
- Connect BROWN cord to terminal marked with a letter "L" or coloured RED.
- Connect BLUE cord to terminal marked with a letter "N" or coloured BLACK.

If this appliance is fitted with a plug which is moulded onto the electric cable (i.e. non-rewireable) please note:

1. The plug must be thrown away if it is cut from the electric cable. There is a danger of electric shock if it is subsequently inserted into a socket outlet.
2. Never use the plug without the fuse cover fitted.
3. Should you wish to replace a detachable fuse carrier, ensure that the correct replacement is used (as indicated by marking or colour code).
4. Replacement fuse covers can be obtained from your local dealer or most electrical stockists.

FUSE RATING

The fuse in the plug must be replaced with one of the same rating (**13 amps**) and this replacement must be approved to BS1362.

We recommend that this machine is connected to the mains supply via a Residual Current Device (RCD)

If in any doubt, DO NOT attempt any connections or repairs yourself. Consult a qualified electrician, your Clarke dealer,

or telephone **CLARKE International Service Dept. on: 020 8556 4443**

or, e-mail : **Service@clarkeinternational.com**

air

Clarke

PARTS IDENTIFICATION



PREPARATION FOR USE

The compressor **MUST** be filled with oil before use. A 500mL bottle of Synthetic Oil is provided.

Remove the travel plug, fitted to the Oil Filler/Breather, and fill with oil using the funnel provided, so that the level is midway across the Oil Sight Glass (indicated in Fig.1).

When satisfied, place the breather, contained in the bag of loose parts, firmly on to the Filler/Breather spout.



OPERATION

Firstly, ensure the compressor is on level ground...do not allow it to run if it is standing on an incline.

Check also that the mains voltage corresponds with that shown on the data label on the side of the compressor.

Ensure that the ON/OFF switch, mounted on the Pressure Regulator (shown in fig. 3), is turned to the '0' (OFF) position, then plug in and switch ON at the mains supply.

1. To start the compressor, turn the ON/OFF switch to the '1' (ON) position - the motor should start immediately.

NOTE: Should the motor fail to start immediately, it is possible that the air receiver is already full of air. Check the tank pressure gauge (see fig. 4). If you release air, by opening the air drain valve (see fig. 1), the motor will start automatically once the cut-in pressure is reached.

Clarke



Before connecting your airline to the compressor, allow it to run for 10 - 15 seconds, with the air drain Valve, (see, Fig. 1) completely open to permit a good distribution of the lubricating oil.

2. Close the outlet tap then connect one end of suitable air hose to the outlet connector (see Fig. 1) , and the other end to the equipment to be used.
3. Set the outlet pressure by adjusting the Pressure Regulator.

To do this, lift the Pressure Regulator Knob, and turn it clockwise to increase pressure, anticlockwise to decrease as noted on the Outlet Gauge.

To lock the Regulator Knob and hence the outlet pressure, push the Regulator Knob down until it clicks into place.



Fig.4

NOTE: For most spray work do not exceed 50 psi (unless following paint manufacturer's instructions).

For other airline equipment such as, tyre gauges, staple guns, paraffin guns etc., it may be necessary to set the operating pressure at a higher (or lower) level.

IMPORTANT:

Always refer to the accessory manufacturers recommendations for optimum operating pressures for their equipment.

4. With the operating pressure set, reopen the air outlet tap.
5. The Pressure Switch, located within the plastic cover beneath the ON/OFF switch, should not require adjustment. This is an automatic device and has been preset at the factory to stop the motor when pressure in the receiver reaches its maximum, and to start it again when the pressure in the receiver falls to the minimum preset value. This operation is completely automatic and does not affect the spraying process in any way. However, should problems develop with the cut-in, cut out settings, please consult your Clarke dealer, or the Clarke Service Dept..

NOTE:

- a. *If the machine pumps continuously without cutting out then the compressor is too small for the application/tool being used, and damage may result. Consult your Clarke dealer.*
- b. *The motor is protected by a Thermal Overload so that if the motor overheats for any reason - the thermal overload will trip, stopping the motor. Allow a period for the motor to cool down before restarting (15 - 20 minutes).*
- c. **DO NOT exceed the Duty Cycle for the machine (see Specifications).**

SHUTTING DOWN THE COMPRESSOR

1. To shut down the compressor, simply turn the ON/OFF switch to the 'O' (OFF) position.

IMPORTANT:

ALWAYS switch the compressor ON or OFF at the Pressure Switch...NEVER at the mains supply switch

2. Close the air outlet tap and trigger the equipment (spray gun, air tool etc.) to release air from the air hose before disconnecting the hose from the machine.
3. Before transporting your compressor or when leaving overnight, expel all air from the receiver by opening the drain valve - Fig 5.

Fig.5



IMPORTANT:

DO NOT FORGET to close the valve again when the tank is empty, particularly if the compressor may not be used for some time.

MAINTENANCE

DAILY

1. Check the oil level before you start and top up if necessary - use Synthetic Air Compressor Oil ONLY, available from your Clarke dealer.. **Part No. 3050795**
The oil level is checked by viewing the oil sight glass, see Fig. 1.

To add oil, proceed as follows:

Remove the air breather (see Fig.7), and top up until the oil level is midway on the oil sight glass.

2. Drain any condensate that may have accumulated in the air outlet filter, by pushing the valve (arrowed in Fig. 6), upwards, with the tank under pressure.
3. When you have finished with the compressor, **ALWAYS** open the drain valve to expel all air, and to allow any condensate to drain off.

DO NOT FORGET to close the valve again when the tank is empty.

NOTE: In order to drain condensate by opening the drain valve, the tank MUST be under pressure.

Fig.6



PERIODICALLY

1. **Renew Air Breather** every 500 hours of operation.
2. **Drain and replace the oil** annually, as follows:
 - (i) Slacken off the screw securing the Compressor Head Securing Collar, shown in Fig. 8, and remove the collar.
 - (ii) Pull off the Head, complete with sealing ring.
 - (iii) Tilt the compressor carefully on to its side, as shown in fig. 8, so that the oil may be drained into a suitable container.
Dispose of the oil according to local ordinances.
 - (iv) Reassemble the head ensuring the sealing ring is in perfect condition and is located correctly.




Fig.7



Fig.8

IMPORTANT! USE ONLY SYNTHETIC OIL, available from your CLARKE dealer.

3. **Check the time it takes to fill the air tank**, periodically, as follows:
 - (i) Ensure the tank is fully drained and the drain tap and outlet tap firmly closed.
 - (ii) Start compressor and check to ensure there are no leaks, using soapy water on all joints. Should any leak be apparent, stop the compressor, drain the tank and rectify the leak before proceeding.
 - (iii) **The time taken to charge the tank is 220 seconds at 20 degrees C, \pm 5%**
 - (iv) Check to ensure the cut-out pressure is 8bar (120psi), if not, consult your Clarke dealer.

Should the tank charging time be excessive, and no leaks are apparent, consult your Clarke dealer.

4. **Check the Air Filter** Should the air filter become dirty, consult your Clarke dealer.

5. **Check the Non-Return Valve**

Should the tank pressure decrease for no apparent reason, it is possible that the non-return valve is leaking. To check, ensure the tank is under pressure and the machine switched OFF, then disconnect the flexible pipe (A Fig 9) from the compressor head to the pressure valve. If air is found to be leaking, empty the tank then dismantle the non-return valve as follows:




Fig.8

air

Clarke

Carefully unscrew the non return valve assembly from the vertical hex. riser, then disassemble. Clean or renew the rubber disk before reassembling.



With the valve restored, start the machine with the flexible pipe disconnected to check for leaks. If leaks persist, renew the valve assembly, otherwise reconnect the flexible pipe.

FAULT FINDING

PROBLEM	PROBABLE CAUSE	REMEDY
The compressor will not start, or stops and will not start again.	Bad connections. Blown fuse Overload cutout switch has tripped.	Check the electrical connections. Clean and tighten as necessary. Replace fuse Wait 25-20 mins before attempting to restart
Compressor does not start.	Air receiver charged	Open drain valve to expel air. Compressor should start again when pressure reduces to approx. 95 psi.
The compressor does not reach the set pressure and overheats easily.	Inlet Air Filter is blocked NOTE: It is also possible that you are using more air than the compressor is capable of delivering.	Renew Oil Filler/Air Filter plug
Air leaking from the pressure switch valve when the compressor is not running.	Faulty non-return valve.	First drain the receiver completely of air. Renew the non-return valve.
Air pressure from the regulator will not adjust.	The diaphragm within the regulator body is broken.	Replace Regulator
Compressor operating, but no air from outlet	Inlet Air Filter Blocked Pressure Regulator closed Drain valve open Bleed Pipe (from Pressure Switch to non-return valve) broken or disconnected	Renew Oil Filler/Air Filter Plug Turn Regulator clockwise to set required pressure Close Drain Valve Reconnect or replace Bleed Pipe



ACCESSORIES

Your Shhh Air Compressor can be used in conjunction with a range of optional accessories for inflating tyres, air brushing, stapling, blowing and many other uses. For details contact your local Clarke dealer.

A complete kit - **Model KIT 600**, illustrated below, is available from your Clarke dealer, ideal for many applications..... **Please quote part number 3110150**



The accessories are also available separately:

Should you experience any difficulties obtaining accessories, please contact the Clarke sales department (telephone 01992 565300) for details of your nearest dealer.