

A SELECTION FROM THE VAST RANGE OF

ClarkeTM

QUALITY PRODUCTS



AIR COMPRESSORS
From DIY to industrial. Plus air tools, spray guns and accessories.

GENERATORS
Prime duty or emergency standby for business, home and leisure.

POWER WASHERS
Hot and cold, electric and engine driven - we have what you need.

WELDERS
Mig, Arc, Tig and Spot. From DIY to auto/industrial.

METALWORKING
Drills, grinders and saws for DIY and professional use.

WOODWORKING
Saws, sanders, lathes, mortisers and dust extraction.

HYDRAULICS
Cranes, body repair kits, transmission jacks for all types of workshop use.

WATER PUMPS
Submersible, electric and engine driven for DIY, agriculture and industry.

POWER TOOLS
Angle grinders, cordless drill sets, saws and sanders.

STARTER/CHARGERS
All sizes for car & commercial use.



REGISTRATION FORM

Please enter all details, detach at the line above, and post to.

Customer Services Department, Clarke International, Shrubland Road, London E10 7RB

Model CS1055 & CS1190

Name

Address

Post Code

Serial Number Key Number

Date Purchased Place Purchased

ClarkeTM STRONG-ARM

FIRE SAFE



**Model Nos.
CS 1055 & CS 1190**

Part Nos. 7710030 & 7710040

The four numbers of your safe's combination are:

1 _____ 2 _____ 3 _____ 4 _____

STRONG-ARM

Thank you for purchasing this CLARKE Strongarm Fire Safe which is designed to provide you with maximum security and many years of protection for your valuables and cherished possessions.

Please read this information booklet thoroughly in order that you may familiarise yourself with all aspects of the safe including its installation and operation.

For security reasons, it is of the utmost importance that you let your combination be known to as few people as possible.

We strongly advised that you **DO NOT** store any medicines in the safe to which you may require quick access.

LIMITED WARRANTY

If your CLARKE STRONGARM safe fails to operate due to manufacturers defect at any time within one year of purchase, we will, at our discretion, repair or replace the unit at no charge to the original owner. Goods should be returned, postage paid, to CLARKE International, at the address given in the Warranty Registration form.

Please retain your receipt as proof of date of purchase.

This warranty shall be void if the product has been damaged by improper installation, neglect, accident, misuse, exposure to extreme heat or humidity, or as a result of service or modification not authorised by CLARKE International.

All costs of removal and reinstallation of the product are the owners responsibility.

No other expressed warranty is given. Repair or replacement of the product is our only liability.

In no event shall CLARKE International be liable for consequential or incidental damages.

This does not effect your statutory rights.

UNPACKING

On unpacking your safe open it, according to the instructions below, and remove the contents. In the case of the CS1055, this includes the anchor 'Break Head' bolts - used for mounting purposes. (The procedure for mounting the CS1055 is described later in this booklet).

When you subsequently open the safe, follow the instructions given under 'Opening the Safe'.

REGISTRATION

Please ensure you complete the Registration form on the back page of this booklet, remembering to include the serial number of your safe and the key number.

The serial number is to be found printed on a small foil label on the lower L.H. corner of the R.H. side - CS1055, and lower R.H. front corner - CS1190. Record the serial number also for your own use in the event the foil label becomes detached or unreadable, and the key number in the event you lose the key. Remember, **DO NOT store these numbers in the safe.**

Forward the Registration Card to the Customer Service Manager at Clarke International at the address shown on the registration form.

If your combination or key is lost or misplaced, you may contact Clarke International, Customer Services Department with a written request for your combination numbers or a replacement key, quoting your serial number.

If your registration is on file, the combination will be returned to you in written form. There will be a small charge made for a replacement key.

If you fail to register and subsequently lose your combination or key, we are unable to provide you with replacements. It is therefore in your own interest to register.

OPENING THE SAFE

Your combination is stamped on the front cover and has 4 numbers. To open the safe, please follow these simple instructions:

1. Turn the dial to the right, passing the first number four times and stopping at that number the next time around.
2. Turn the dial to the left, passing the second number two times and stopping at that number the next time around.
3. Turn the dial to the right, passing the third number one time and stopping at that number the next time around.
4. Turn the dial to the left, to the fourth number and stop.
5. Insert the key in the cylindrical lock and turn it clockwise to open

CLOSING THE SAFE

Close the safe door and in the case of the CS1055, turn the key anticlockwise to lock. (The CS1190 has automatic locking).

REMEMBER to spin the dial in order to reset the tumblers - both models.

SPECIFICATIONS

	CS1055	CS1190
Firesafe at 925°C	60 min.	120 min.
Capacity:	1.0 cu ft	2.2 cu ft
Dimensions (cm):	34X39X44	46x50x65
Weight:	31kg	73kg

MOUNTING YOUR SAFE.

(CS1055 only)

The CS1055 safe may be mounted on a shelf or other furniture of your choice.

Please bear in mind, that for maximum security the shelf/furniture must be of sufficient strength, or reinforced to prevent the removal of the safe by force. REMEMBER, your safe is only as secure as its mountings. The weight of the safe itself, may not deter an intruder from carrying it off to open at leisure.


Plan the installation carefully, and if necessary, seek expert advice.

There are four threaded holes in the base of the safe and four 'Break Head' bolts are provided for mounting to a shelf or other furniture.

Use the template provided to drill four mounting holes in the shelf, or furniture.

Remove the screws securing the rubber feet. Insert the break head bolts through the mounting surface and the rubber feet and screw them into the threaded holes in the base of the safe.

Tighten the bolts progressively until each bolt head snaps off.



NOTE:

The rubber feet may be omitted if desired to avoid having a gap between the safe and the furniture. If there is sufficient clearance around the safe, this gap could be used to insert a lever to pry the safe away from a wooden mounting.

The Break Head bolts may be cut to length if desired.

Model CS1055 & CS1190

ClarkeTM
INTERNATIONAL

Customer Services Department, Shrubland Road, London E10 7RB