

CLARKE®

METALWORKER



BENCH GRINDER STAND

MODEL NO: CBGS1

PART NO: 6501140

GUARANTEE

This CLARKE product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt as proof of purchase. This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for its intended purpose. Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission without permission. This guarantee does not effect your statutory rights

GC0117

Thank you for purchasing this CLARKE Bench Grinder Stand, which is designed for general workshop use.

The CLARKE Bench Grinder Stand will accommodate most bench grinders with 2 or 4 bolt mountings.

Its heavy duty, cast iron construction ensures security and stability of the bench grinder, which may be further enhanced by anchoring the stand to the floor.

To assemble the stand, lower the tube into its housing on the base and secure with the two screws provided. Similarly, locate the table mounting on to the tube, again securing with the two screws provided.

The Bench Grinder should be mounted with its centre of gravity as near to the centre of the table as possible, ensuring that the correct size bolts are used for the sizes of holes in your grinder mountings and flat washers are used to compensate for the oversize holes in the table.

The nuts should be nipped up firmly but be careful not to overtighten them.

An 12 mm hole is provided on the end of each foot to allow the stand to be anchored to the floor. Ensure the floor is level before the stand is secured.

Site the grinder in a well lit area, not where you will be working in you own light.

Ensure an adequate electrical supply is close at hand - avoid long extensions which are a hazard in a workshop environment.

SPECIFICATIONS

Table size	247 x 277 mm
Height	910 mm
Net weight	15 kg
Part No	6501140

A complete range of CLARKE Bench Grinders is available from your CLARKE dealer.

For spare parts and servicing, please contact your nearest dealer, or

CLARKE International, on one of the following numbers:

PARTS & SERVICE- 0208 988 7400

PARTS E-MAIL - Parts@clarkeinternational.com

SERVICE E-MAIL - Service@clarkeinternational.com