

Clariflo®



HALOGEN WORKLIGHT

MODEL NO: HLC400

PART NO: SEE 5460680

ASSEMBLY & USER INSTRUCTIONS



ORIGINAL INSTRUCTIONS

GC1119 -ISSUE 2

INTRODUCTION

Thank you for purchasing this CLARKE 400W (230V halogen flood light with handle and grill. This worklight is for domestic use and similar applications but not to be used on construction sites. The unit has a fixed height at floor level.

Before attempting to use this product, please read this manual thoroughly and follow the instructions carefully. In doing so you will ensure the safety of yourself and that of others around you, and you can look forward to your purchase giving you long and satisfactory service.

TECHNICAL INFORMATION

Model	HLC400
Model type	0203
Dimensions (L x W x H)	225 x 205 x 310 mm
Weight	1.5 kg
Tilt adjustment	-90 to + 90°
Operating Temperature	-20°C to + 50°C
Power Supply	230V 50Hz
Rated input current	1.74 A
Insulation Class	I
IP Rating	IP54 (exterior use)
Energy Efficiency Class#	C class tube
Weighted energy consumption	400 kWh /1000h
Colour Temperature#	2900 K
Efficiency#	21.4 lm/W
Lumen output # (luminous flux)	8545
Bulb (Halogen Tube Type)	R7s-J118

- values given for the bulb supplied

GUARANTEE

This product is guaranteed against faulty manufacture for a period of 12 months from the date of purchase. Please keep your receipt which will be required as proof of purchase.

This guarantee is invalid if the product is found to have been abused or tampered with in any way, or not used for the purpose for which it was intended.

Faulty goods should be returned to their place of purchase, no product can be returned to us without prior permission. This guarantee does not effect your statutory rights.

SAFETY PRECAUTIONS

1. This worklight must never be immersed in water.
2. Do not look directly into the lamp when switched on as this can harm the eyes.
3. If used with an extension cable always ensure that the extension cable is fully unwound.
4. Do not use this worklight if it has a broken lens, casing or damaged cable
5. Always unplug the worklight before moving it or performing maintenance. Do not touch the lamp when your hands are wet.
6. Do not attempt to disassemble or repair the worklight.
7. Always unplug the worklight when it is not in use.
8. Never unplug the worklight by pulling the cable, always hold the plug.
9. Never use the worklight if the cable or plug are damaged.
10. Always stand on firm, level ground.
11. Do not cover the halogen bulbs or place combustable materials on top of the worklight.
12. Do not place within 1m of combustable materials.

SAFETY SYMBOLS

The following symbols appear on the unit.

Hot surface, do not touch.



Do not cover



DO NOT COVER

ELECTRICAL CONNECTIONS



WARNING: READ THESE ELECTRICAL SAFETY INSTRUCTIONS THOROUGHLY BEFORE CONNECTING THE PRODUCT TO THE MAINS SUPPLY.


Connect the mains lead to a standard, 230 Volt (50Hz) electrical supply through an approved 13 amp BS 1363 plug, or a suitably fused isolator switch. If the plug has to be changed because it is not suitable for your socket, or because of damage, it must be removed and a replacement fitted, following the wiring instructions shown below. The old plug must be discarded safely, as insertion into a power socket could cause an electrical hazard.



**WARNING: THE WIRES IN THE POWER CABLE OF THIS PRODUCT ARE COLOURED IN ACCORDANCE WITH THE FOLLOWING CODE:
BLUE = NEUTRAL BROWN = LIVE YELLOW AND GREEN = EARTH**

If the colours of the wires in the power cable do not agree with the markings on the plug,

- The BLUE wire must be connected to the terminal which is marked N or coloured black.
- The BROWN wire must be connected to the terminal which is marked L or coloured red.
- The YELLOW AND GREEN wire must be connected to the terminal which is marked E or \perp or coloured green.




We strongly recommend that this product is connected to the mains supply through a Residual Current Device (RCD)

If you are not sure, consult a qualified electrician.

ASSEMBLY & MOUNTING

The worklight must be mounted on the carry frame as shown:

1. Remove the locking knob from the base section of the carry frame, then insert the tubular base into the frame attachment, as shown.
2. Line up the holes in the two sections of the frame then replace and tighten the locking knob.




MAINTENANCE

Always allow the lamp to cool before performing any maintenance.

The halogen tubes supplied have a life expectancy of approximately 2000 hours and can be fitted/replaced by the user.

1. Remove the screw holding the front of the lamp closed and hinge it away from the lamp.
 - The tube is a simple press-fit in the holder at each end.
2. Do not touch the tube if hot. When handling the new tube use clean paper or cloth...DO NOT allow your fingers to come into contact with the glass. If this happens, clean the glass with methylated spirit.



3. Close the cover and re-tighten the screw.
4. Clean the lens at regular intervals using a non-abrasive glass cleaner.

Further replacement tubes can be obtained from your local dealer or Clarke International Spares Department.

Type R7s-J1 18 - 230V -Max 400W

Clarke Part No. 5460670

CARE & STORAGE

1. When not in use, switch off & unplug from the power supply.
2. Store this worklight in a secure, dry place, out of the reach of children. DO NOT leave it exposed to the elements and avoid direct sunlight, direct heat, rain/moisture etc.
3. Keep the external surfaces clean. Avoid impact damage & do not allow this worklight to come into contact with abrasive or corrosive materials.
4. Do not use solvents, thinners or alcohol for cleaning (with the exception of the halogen tubes), as these chemicals will damage the finish. With the worklight unplugged from the power supply, use a dry cloth to wipe over the components.
5. Only use extension leads that are of an appropriate power rating and suitable for the work environment. Inspect the extension lead regularly and replace if damaged.
6. Never use unauthorised accessories or attachments which may result in personal injury or damage to the product.
7. Do not attempt to repair or modify this product or attempt any electrical repair yourself beyond replacing halogen tubes. Consult the Clarke Service Department on 020 8988 7400.

ENVIRONMENTAL RECYCLING POLICY



Through purchase of this product, the customer is taking on the obligation to deal with the WEEE in accordance with the WEEE regulations in relation to the treatment, recycling & recovery and environmentally sound disposal of the WEEE.

In effect, this means that this product must not be disposed of with general household waste. It must be disposed of according to the laws governing Waste Electrical and Electronic Equipment (WEEE) at a recognised disposal facility.

DECLARATION OF CONFORMITY



Clarke[®]
INTERNATIONAL

Hemnall Street, Epping, Essex CM16 4LG

DECLARATION OF CONFORMITY

This is an important document and should be retained.

We hereby declare that this product(s) complies with the following directive(s):

2014/35/EU *Low Voltage Equipment Directive.*

2011/65/EU *Restriction of Hazardous substances.*

The following standards have been applied to the product(s):

EN 60598-1:2015, EN 60598-2-5:1998, EN 60598-2-7:1989+A2:1996+A13+1997,

EN 62493:2010, EN 62321:2009.

The technical documentation required to demonstrate that the product(s) meet(s) the requirement(s) of the aforementioned directive(s) has been compiled and is available for inspection by the relevant enforcement authorities.

The CE mark was first applied in: 2017

Product Description: 400w Halogen Flood Light with Handle 230V,
Twin 400w Halogen Flood Light with Tripod 230V
400w Halogen Flood Light with Handle 110V,
Twin 400w Halogen Flood Light with Tripod 110V.

Model number(s): HLC400, HLC400T, HLC400/110, HLC400T/110.

Serial / batch Number: 5460680, 5460695, 5460685, 5460690.

Date of Issue: 26/07/2017.

Signed:

J.A. Clarke
Director

A SELECTION FROM THE VAST RANGE OF

Clarke®

QUALITY PRODUCTS

AIR COMPRESSORS

From DIY to industrial, Plus air tools, spray guns and accessories.

GENERATORS

Prime duty or emergency standby for business, home and leisure.

POWER WASHERS

Hot and cold, electric and engine driven - we have what you need

WELDERS

Mig, Arc, Tig and Spot. From DIY to auto/industrial.

METALWORKING

Drills, grinders and saws for DIY and professional use.

WOODWORKING

Saws, sanders, lathes, mortisers and dust extraction.

HYDRAULICS

Cranes, body repair kits, transmission jacks for all types of workshop use.

WATER PUMPS

Submersible, electric and engine driven for DIY, agriculture and industry.

POWERTOOLS

Angle grinders, cordless drill sets, saws and sanders.

STARTERS/CHARGERS

All sizes for car and commercial use.



PARTS & SERVICE: 0208 988 7400

E-mail: Parts@clarkeinternational.com or Service@clarkeinternational.com

SALES: UK 01992 565333 or Export 00 44 (0)1992 565335

Clarke® INTERNATIONAL Hemnall Street, Epping, Essex CM16 4LG
www.clarkeinternational.com