

PARTS LIST

Clarke CAT83 Angle Head Die Grinder	Part Number: 3110815
--	-----------------------------

<u>Quantity</u>	<u>Description</u>	<u>Part Number</u>
1	Throttle Lever	KL0308AH001
1	Spring Pin	KL0308AH002
1	Housing	KL0308AH003
1	Valve Bushing	KL0308AH004
1	O-Ring	KL0308AH005
1	Valve Stem	KL0308AH006
1	O-Ring	KL0308AH007
1	Valve Spring	KL0308AH008
1	Air Controller	KL0308AH009
1	O-Ring	KL0308AH010
1	O-Ring	KL0308AH011
1	Valve Screw	KL0308AH012
1	Bearing	KL0308AH013
1	End Plate	KL0308AH014
2	Pin	KL0308AH015
1	Cylinder	KL0308AH016
1	Rotor	KL0308AH017
4	Blade	KL0308AH018
1	Collar	KL0308AH019

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

Parts List for Clarke P/N 3110815 CAT83 Angle Head Grinder.

1	Steel Plate	KL0308AH020
1	Front Plate	KL0308AH021
1	Bearing	KL0308AH022
1	Spindle	KL0308AH023
1	Lock Ring	KL0308AH024
1	Collet	KL0308AH025
1	Collet Nut	KL0308AH026
1	Exhaust Sleeve	KL0308AH027
1	O-Ring	KL0308AH028
1	Air Inlet	KL0308AH029
1	Spanner 11mm	KL0308AH030
1	Spanner 17mm	KL0308AH031
1	O-Ring	KL0308AH032
1	Clamp Ring	KL0308AH033
1	Air Hose Assembly	KL0308AH034

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

Parts List for Clarke P/N 3110815 CAT83 Angle Head Grinder.