

PARTS LIST

| | |
|--------------------------------------|-------------------------------|
| Clarke – CAT104 IMPACT WRENCH | Part Number: - 3110860 |
|--------------------------------------|-------------------------------|

| <u>Quantity</u> | <u>Description</u> | <u>Part Number</u> |
|-----------------|--------------------|--------------------|
| 1 | PROTECTING SEAL | KL280031 |
| 1 | OIL SEAL | KL004205 |
| 1 | MOTOR HOUSING | KL280001 |
| 1 | SCREW | KL000614 |
| 1 | ANVIL BUSHING | KL280010 |
| 1 | ANVIL COLLAR | KL280028 |
| 1 | O-RING | KL004175 |
| 1 | SPACER | KL280029 |
| 1 | 6" ANVIL | KL280011b6 |
| 1 | HAMMER PIN | KL280016 |
| 1 | HAMMER CAGE | KL280012 |
| 1 | HAMMER | KL280015 |
| 1 | CAM | KL180013 |
| 1 | OIL SEAL | KL004206 |
| 1 | O-RING | KL004108 |
| 1 | FRONT END PLATE | KL280005 |
| 1 | ROTOR BLADE | KL280008 |
| 1 | ROTOR | KL280007B |
| 1 | CYLINDER | KL280006 |
| 1 | REAR WASHER | KL280033 |

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com



| | | |
|---|---------------------|-----------|
| 1 | BALL BEARING | KL002312 |
| 1 | REAR END PLATE | KL280009 |
| 1 | REAR COVER | KL280003 |
| 1 | SPRING WASHER | KL001803 |
| 1 | CAP SCREW | KL000119 |
| 1 | CAP SCREW | KL000110 |
| 1 | PROTECTING RUBBER | KL280032 |
| 1 | SPRING WASHER | KL001802 |
| 1 | VALVE SLEEVE | KL280019 |
| 1 | REVERSE VALVE | KL280020 |
| 1 | REAR GASKET | KL280030B |
| 1 | O-RING | KL004106 |
| 1 | REGULATOR | KL280023B |
| 1 | SCREW | KL000802 |
| 1 | EXHAUST DEFLECTOR | KL280026B |
| 1 | PIN | KL280024 |
| 1 | SPRING | KL250028 |
| 1 | SCREW | KL000609 |
| 1 | TRIGGER | KL280021A |
| 1 | SPRING PIN | KL003301 |
| 1 | SPRING PIN | KL003305 |
| 1 | VALVE STEM | KL280022 |
| 1 | SPRING | KL280025 |
| 1 | AIR INLET (1/4" PF) | KL250024A |
| 1 | BALL BEARING | KL002313 |
| 1 | O-RING | KL004114 |
| | | |
| | | |

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

