

PARTS LIST

Clarke – CAT110 1/2” AIR IMPACT WRENCH	Part Number: - 3120120
---	-------------------------------

<u>Quantity</u>	<u>Description</u>	<u>Part Number</u>
1	PROTECTING RUBBER	RONCAT11001
1	HOUSING	RONCAT11002
1	BOLT	RONCAT11003
1	ANVIL BUSHING	RONCAT11004
1	ANVIL COLLAR	RONCAT11005
1	O-RING	RONCAT11006
1	ANVIL	RONCAT11007
1	HAMMER PIN	RONCAT11008
1	HAMMER CAGE	RONCAT11009
1	HAMMER DOG	RONCAT11010
1	DRIVE CAM	RONCAT11011
1	BALL BEARING	RONCAT11012
1	OIL SEAL	RONCAT11013
1	ROTOR BLADE	RONCAT11015
1	ROTOR	RONCAT11016
1	PIN	RONCAT11017
1	CYLINDER	RONCAT11018
1	BOLT	RONCAT11019
1	REAR END PLATE	RONCAT11020
1	GASKET	RONCAT11021
1	REAR COVER	RONCAT11022

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

Parts List for Clarke CAT110 AIR WRENCH ½” P/N 3120120 Date Issued: 13/10/14

1	WASHER	RONCAT11023
1	BOLT	RONCAT11024
1	PROTECTING RUBBER	RONCAT11025
1	VALVE SLEEVE	RONCAT11026
1	REVERSE VALVE	RONCAT11027
1	O-RING	RONCAT11028
1	VALVE STEM	RONCAT11029
1	WASHER	RONCAT11030
1	STEEL BALL	RONCAT11031
1	INLET SPRING	RONCAT11032
1	AIR INLET PLUG	RONCAT11033
1	DUST FREE COVER	RONCAT11034
1	SPRING	RONCAT11035
1	O-RING	RONCAT11036
1	AIR REGULATOR	RONCAT11037
1	BOLT	RONCAT11038
1	PIN	RONCAT11039
1	TRIGGER	RONCAT11040
1	EXHAUST	RONCAT11041
1	BOLT	RONCAT11042
1	SCREW	RONCAT11043
1	SPRING	RONCAT11044
1	PIN	RONCAT11045

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

Parts List for Clarke CAT110 AIR WRENCH ½" P/N 3120120 Date Issued: 13/10/14

