

PARTS LIST

Clarke – CFC500F CRANE	Part Number: - 7610610
-------------------------------	-------------------------------

<u>Quantity</u>	<u>Description</u>	<u>Part Number</u>
1	HOOK&CHAIN CFC CRANE	HT100010
1	WHEEL ASSY.CFC CRANE	HT100013
1	CASTOR ASS.CFC CRANE	HT100014
1	REAR SUPPORT CFC500F	HT500101
1	FRONT LEG CFC500F	HT500102
1	EXT.SUPPORT CFC500F	HT500103
1	MAIN SUPPORT CFC500F	HT500104
1	SUPPORT BRK. CFC500F	HT500105
1	BOOM CFC500F	HT500106
1	BOOM EXT. CFC500F	HT500107
1	RAM CFC CRANE	HT500108
1	VALVE BODY RAM ASSY	HT50010801
1	COPPER WASH.RAM ASSY	HT50010802
1	CYLINDER RAM ASSY	HT50010803
1	O RING RAM ASSY	HT50010804
1	O RING RET. RAM ASSY	HT50010805
1	RAM RAM ASSY	HT50010806
1	TOP NUT RAM ASSY	HT50010807
1	O RING RAM ASSY	HT50010808
1	SEAL.GASKET RAM	HT50010809
1	OIL CHAMBER RAM	HT50010810
1	OIL PLUG RAM	HT50010811
1	SEAL RING. RAM	HT50010812

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com

1	TUBE RAM	HT50010813
1	STEEL BALL. RAM	HT50010816
1	SEAL RING RAM	HT50010817
1	REL.VALVE RAM	HT50010818
1	STEEL BALL RAM	HT50010819
1	COPPER WASH.RAM	HT50010820
1	PUMP CYL. RAM	HT50010821
1	O RING RAM	HT50010822
1	BACKUP RING.RAM	HT50010823
1	PLUNGER RAM	HT50010824
1	LINK PIN RAM	HT50010825
1	HANDLE SOC. RAM	HT50010827
1	CONN.PIN RAM	HT50010828
1	COTTER PIN. RAM	HT50010829
1	STOP BLOCK. RAM	HT50010830
1	SPRING RAM	HT50010831
1	SCREW RAM ASSY	HT50010832
1	REPAIR KIT RAM ASSY	HT50010833
1	O RING CFC500F	HT50010834
1	ROD CFC500F	HT50010835
1	HANDLE CFC500F	HT500109
1	HOOK/CHAIN CFC500F	HT500110
1	GRIP CFC500F	HT500111
1	BOLT M12x30 CFC500F	HT500112
1	EYE BOLT M14 CFC500F	HT500115
1	MODEL/SERIAL NO.CFC	HT500116
1	WEIGHT IND.LABEL CFC	HT500117
1	ACCESS.PACK CFC500F	HT500ACC

Parts and Servicing

For parts and servicing, please contact your nearest dealer or CLARKE International on the following number; 020 8988 7400 or e-mail as follows; parts@clarkeinternational.com or service@clarkeinternational.com